

Network Camera IP7137

Quick Installation Guide

This guide describes the basic functions of IP7137. All detailed information is described in the user's manual.

E-mail: sales@vivotek.com http://www.vivotek.com



Warning Before Install

- Power off the Network Camera as soon as it is found smoking or smelt unusual.
- Keep the Network Camera away from the water. If the Network Camera is wet, power off immediately.



Contact your distributor when such cases happen.




Contact your distributor when such cases happen.

- Do not place the Network Camera around the heat sources, such as television or oven.
- Refer to your user's manual for the operating temperature.



Keep the Network Camera away from the direct sunlight.





Do not place the Network Camera in high humid environments.



Do not place the Network Camera on unsteady surfaces.




Do not disassemble the Network Camera.



Do not insert any object into the Network Camera, such as needles.



On not touch the Network Camera when it's lightening.



Do not drop the Network Camera.





OIP7137



OCamera Stand



Quick Installation Guide
Warranty Card



Power Adapter




Software CD






2 Physical Description

Front Panel




Rear Panel






Install Your Network Camera in Ethernet Network



- 1.Use Ethernet cable to make connection from Ethernet port to the hub.
- *Use Category 5 Cross Cable when the Network Camera is directly connected to PC.



- Run the "Installation Wizard" under the Software Utility directory from software CD.
- 2. The program will search the servers or cameras on the same LAN.




5 The Internet Explorer Connects to the Network Camera





Set up Your Wireless Configuration for the Network Camera

- 1. Check the SSID currently set on your wireless access point (AP).
- 2.Go to IP7137's Configuration > Wireless LAN



Note:

- 1.SSID abbreviated from Service Set Identifier is the name assigned to the wireless network. The IP7137's factory SSID setting is set to "default".
- 2.Select "Ad-Hoc" wireless mode if you want the IP7137 to communicate without using an AP or wireless router.

For setup further configuration, please check user's manual on the software CD.